




SPRINGBACK
DECOYS

INSTRUCTIONS


1

At rest, the heavy-duty string sits coiled inside the decoy. The weight fits onto the bottom of the decoy and a release tab is positioned towards the rear of decoy.



2

To detach the weight from the decoy, slide the weight from the weight holder and press the release tab to pull out the weight to the desired depth—up to 10 feet. To set the string at different lengths, hold the tab and release it when you have set the weight to the desired depth.



3

To retract the weight, simply press the release tab to recoil the weight back into the decoy and snap the weight back into place.



Be sure to check out our instructional videos on springbackdecoys.com, [YouTube](#) or [Instagram](#).

